

Thank you for the purchase of our SwayLOC JK Kit.

IF you have this doc in the pile of docs, then you have the newest version. We are replacing the white bushing shims that locate the bar side to side with the same clamps that we are using on the JL/JT version kits. This allows for tighter positioning and easy adjustability.

Installation is super simple, loosen the 2, 2piece clamps and place them between the mounts on the torsion bar during assembly. IF you forget, no problem, unscrew the clamping bolts and put them on after.

Also note that the white bushings flanges need to be orientated to the inside of the mounts. This will allow the clamps to mount flush to the flanges and once you have the bar in place, arms positioned and run the SwayLOC up/down thru the swing to check for clearance, simply slide the clamps tight to the white bushings and tighten them to hold the bar from moving side to side.

The image below will show the clamps and white bushings on the bar as they need to be placed.

